



- RFI # SUMMARY:-**
- 1 PLEASE VERIFY EXISTING PILE PROFILE AND LOCATION IN FIELD.
 - 2 PLEASE VERIFY DIMENSION.
 - 3 DO WE NEED TO PROVIDE ANY STIFFNER PLATE OR SPACER PLATE AT THIS LOCATION. PLEASE ADVISE.
 - 4 PLEASE CONFIRM THE HANDRAIL POST TO POST MAXIMUM SPACING.
 - 5 WE ARE TRIMMED THE PLATE TOP AS SHOWN FOR ANGLE AND GRATING PLEASE REVIEW AND CONFIRM.
 - 6 WE HAVE ADDED 7mm GAP FOR ANGLES AT THIS LOCATION PLEASE CONFIRM.
 - 7 WE HAVE OFFSETTED THE BOLTS AS SHOWN PLEASE REVIEW AND CONFIRM.
 - 8 WE HAVE ADDED BOLTED GUSSET PLATE CONNECTIONS AT THESE LOCATIONS ALSO. PLEASE CONFIRM.
 - 9 PLEASE REVIEW THE CONNECTION DETAIL AND CONFIRM THE REQUIREMENT OF SPACER PLATE, LIMP SECTION OR TEFLO PLATES.